



Karlsruhe Chart of the Nuclides Nuclear Data

Zsolt Sóti

**Institute for Transuranium Elements - Karlsruhe
Joint Research Centre**



Overview

Nuclide Charts

Karlsruhe Chart of Nuclides

Electronic Nuclide Charts in Nucleonica


Nuclear Data Search in Nucleonica

Fission Yields

What is a Nuclide Chart?

Nuclide charts are essentially a plot of the number of protons versus the number of neutrons in atomic nucleus.


Stable nuclides fall in a narrow range of neutron to proton ratio. The stability of nuclei is extremely significant for special (magic) number of protons and neutrons.



Nuclide boxes

The charts contain information on the basic properties of known nuclides.







Each nuclide is represented by a box containing basic nuclear data



This data consists of the half-life, neutron cross sections, main gamma lines, etc... An important characteristic of the chart is the use of colours to denote the mode of decay, half-life, or cross-sections. If the nuclide has one or more metastable states, the box is subdivided into smaller boxes for each state.

KNC – Colours of decay modes











O [15.99903; 15.99977] σ 0.00029	O 12 580 keV $7.9 \cdot 10^{-22}$ s 2p β^+ ?	O 13 8.58 ms β^+ 16.7... βp 1.44, 6.44... γ (4439*, 3500...)	O 14 70.59 s β^+ 1.8, 4.1... γ 2313...	O 15 2.03 m β^+ 1.7 no γ	O 16 99.757 σ 0.00019	O 17 0.038 σ 0.00054 $\sigma_{n,\alpha}$ 0.257	O 18 0.205 σ 0.00016	O 19 27.1 s β^- 3.3, 4.7... γ 197, 1357...	O 20 13.5 s β^- 2.8... γ 1057...	O 21 3.4 s β^- 6.4... γ 1730, 3517 280, 1787...	O 22 2.25 s β^- γ 72, 637 1862...
N 10 2.3 MeV $200 \cdot 10^{-24}$ s p?	N 11 ~0.77 MeV? ~ $590 \cdot 10^{-24}$ s? p	N 12 11.0 ms β^+ 16.4... γ 4439... $\beta\alpha$ 0.2...	N 13 9.96 m β^+ 1.2 no γ	N 14 99.636 σ 0.080 $\sigma_{n,p}$ 1.93	N 15 0.364 σ 2.4 E-5	N 16 5.3 μ s 7.13 s β^- 4.3 10.4... γ 6129 7115... $\beta\alpha$ 1.76...	N 17 4.17 s β^- 3.2, 8.7... βn 1.17, 0.38... γ 871, 2184 $\beta\alpha$ 1.25, 1.41	N 18 0.63 s β^- 9.4, 11.9... γ 1982, 822 1652, 2473... $\beta\alpha$ 1.08, 1.41... βn 1.35, 2.46...	N 19 336 ms β^- γ 96, 1983*, 3851 1376, 2475... βn 1.054, 0.462 2.655...	N 20 136 ms β^- , γ 1674, 96* 1376*... βn 2.071 1.098...	N 21 82.9 ms β^- βn 0.33, 0.44 4.98, 2.85... γ 1674*, 2397* 1222...
C 9 126.5 ms β^+ 15.5... βp 8.24, 10.92... $\beta\alpha$	C 10 19.308 s β^+ 1.9... γ 718, 1022	C 11 20.38 m β^+ 1.0 no γ	C 12 98.93 σ 0.0035	C 13 1.07 σ 0.0014	C 14 5730 a β^- 0.156 no γ	C 15 2.45 s β^- 4.5, 9.8... γ 5298...	C 16 0.747 s β^- 4.7, 7.9... βn 0.79, 1.72	C 17 193 ms β^- βn 1.62... γ 1375, 1849 1906...	C 18 92 ms β^- γ 2614, 880 2499... βn 0.88, 1.55...	C 19 49 ms β^- βn 1.01, 0.46... $\beta 2n$	C 20 14 ms β^- βn
B 8 770 ms β^+ 14.1... $\beta 2\alpha$ ~1.6, 8.3	B 9 0.54 keV $800 \cdot 10^{-21}$ s p	B 10 19.9 σ 0.3 $\sigma_{n,\alpha}$ 3840 $\sigma_{n,p}$ 0.007	B 11 80.1 σ 0.005	B 12 20.20 ms β^- 13.4... γ 4439... $\beta\alpha$ 0.2...	B 13 17.33 ms β^- 13.4... γ 3684... βn 3.6, 2.4...	B 14 13.8 ms β^- 14.0... γ 6090, 6730 βn	B 15 10.4 ms β^- 16.0, 18.4... βn 1.77, 3.20...	B 16 < $190 \cdot 10^{-12}$ s n?	B 17 5.1 ms β^- βn , $\beta 2n$ $\beta 3n$, $\beta 4n$	B 18 <26 ns n?	B 19 2.92 ms β^- βn $\beta 2n$
Be 7 53.22 d ϵ γ 478 $\sigma_{n,p}$ 38820	Be 8 5.57 eV $67 \cdot 10^{-18}$ s α 0.046	Be 9 100 σ 0.0078	Be 10 $1.387 \cdot 10^6$ a β^- 0.6 no γ σ < 0.001	Be 11 13.8 s β^- 11.5... γ 2125, 6791... $\beta\alpha$ 0.77, 0.29	Be 12 21.50 ms β^- 11.7... βn	Be 13 0.5 ns n?	Be 14 4.35 ms β^- βn <0.8, 3.02 3.52..., $\beta 2n$ γ 3528*, 3680*	2.53E-5 12 14			




Chemical elements - white

Multiple decay modes


Large and small triangles



Decay processes on the KNC



Decay processes on the KNC



More info...

Home | Sitemap | About Us

nucleonica

... web driven nuclear science

Home

- Welcome
- Free Access
- Premium Membership
- Our Customers
- Nucleonica [blog]
- Nucleonica [wiki]
- Forum
- Karlsruhe Nuclide Chart
- Online Shop
- Educational Resources
- Training Courses
- Ask an Expert
- FAQ
- Careers



Logged in as: zsolt (Administrator) Search Forum Calculator Privacy Legal

nucleonica

... web driven nuclear science

Applications Data Knowledge My Preferences Print Networking Nuclear Science Help New Browser Tab New Alerts Logout

> Nucleonica Networking

- >> Networking
- >> My Profile
- >> My Community
- >> My Mailbox
- >> My Groups
- >> My Settings

> Tools

- >> Forum
- >> webGraph

> Applications Portal

- >> nuclear science

Important Information for all Nucleonica Users

The Nucleonica Team would like to inform you that as of 1st Dec. 2011 we will be restricting access to Nucleonica. For users who have Free accounts, access will be restricted to around 5-10 nuclides but with access to many of the applications and features. This will allow newly registered users the opportunity to get a feel for Nucleonica and to try out the various modules. For those who have been using Nucleonica for some time, we recommend an upgrade to the Premium access with full unrestricted access to over 3800 nuclides and isomers and to all applications and features. We would also be happy to offer Free access users a trial Premium account to experience unrestricted, cost-free access for a limited period of time. For trial Premium account enquiries please contact info@nucleonica.com.

For details on the access restrictions please see the [List of Features](#).

More general information on the

Welcome, Zsolt

My Settings

My Profile My Community

> My Community Events

- You have 0 new messages
- You have 0 new contact list requests

> Recent Nucleonica Members

- Karen Haroyan
- Bisma Barron Patrianesha
- Konrad Wysoglad
- VENKATA SUBRAMANIAN DHANDAPANI

>> Nucleonica Forum

Karlsruhe Nuclide Chart data in Nucleonica?

It seems that Nucleonica only uses the 7th edition of Karlsruher Nuklidkarte instead of the obviously

nucleonica [wiki]

special page

All pages

All pages

Display pages starting at:

Display pages ending at:

Namespace: Help

- Cambio File Converter
- Decay Engine
- Dose Coefficients (ICRP 68 & 72)
- E-Ship++
- Gamma Library
- Mass Activity Calculator
- Neutron Activation with webKORIGEN
- Nucleonica Database
- Nuclide Datasheets++
- Nuclide mixtures
- Scripting language documentation
- Virtual Cloud Chamber
- WebKORIGEN
- Conference Calendar
- Decay Engine++
- Dosimetry & Shielding
- EasyMonteCarlo
- Gamma Spectrum Generator
- Mass Activity Converter
- Nuclear Data Retrieval
- Nucleonica for Smartphones
- Nuclide Explorer
- Physical Constants
- Transport & Packaging
- WESPA
- WebKORIGEN Case Studies

support

- Training Courses
- Case Studies
- Nucleonica Support


tools

- Recent changes
- Random page


search

Go Search


The Roll Map (170x120cm). Now available




The Fold-out Chart (A4). Now available




The Wallchart, 95 cm x 139 cm. Now available. See a giant version of this at the Technical University of Munich



The Auditorium Chart, 43 cm x 316 cm. Now available



The Karlsruhe Nuclide "Carpet" with CERN logo (approximate dimensions 100 cm x 650 m). Now available



This page is supported and maintained within the [Nucleonica](#) nuclear science portal.

Pages in category "KNC"

The following 13 pages are in this category, out of 13 total.

5	H	P
<ul style="list-style-type: none">50th Anniversary of the KNC	<ul style="list-style-type: none">Historical	<ul style="list-style-type: none">Publications & Press
C	I	S
<ul style="list-style-type: none">Contemporary Science Posters	<ul style="list-style-type: none">Ideas for Farewell Gifts	<ul style="list-style-type: none">ScienceCinemaShort History of the KNC
D	K	
<ul style="list-style-type: none">Decay Schemes	<ul style="list-style-type: none">Karlsruhe Nuclide Chart, 7th edition	
F	N	
<ul style="list-style-type: none">FAQs (KNC)	<ul style="list-style-type: none">Nuclide "Carpet"	
G	O	
<ul style="list-style-type: none">General References	<ul style="list-style-type: none">Online Shop	

Decay Schemes




55 Cs 137 (Z=55, N=82)

The nuclide Cs 137 is an isotope of the element caesium (atomic number 55, chemical symbol Cs). There are 137 nucleons in the nucleus consisting of 55 protons and 82 neutrons. Cs 137 is radioactive with a half-life of 30.08 years.

Ba 137 2.55 m 11.232 I _γ 662 σ 5	Ba 138 71.698 σ 0.41
Cs 136 19 s 13.16 d β ⁻ 0.3 0.7... γ 819 1048... σ 1.3	Cs 137 30.08 a β ⁻ 0.5, 1.2... γ (284) m, g σ 0.20 + 0.07

Cs 137: Extract from the Karlsruhe Nuclide Chart, 8th Edition (2012)



Cs137 Decay Scheme

Main Radiations	Branching	E
β ⁻	0.947	0.514 MeV
γ(ce)	0.851	662 keV
β ⁻	0.053	1.176 MeV
β ⁻	0.0006	0.892 MeV
γ	0.0006	284 keV

The colour blue indicates that the nucleus decays by β⁻ emission. Cs 137 is characterised by the emission of several β⁻ particles with different endpoint energies. The most probable β⁻ emission is at 0.5 MeV whereas the highest energy emission occurs at 1.2 MeV. Additional beta particles are also emitted indicated by the dots. The box entry m indicates that the main β⁻ decay is to the metastable state (94.7%) Ba 137m.

The gamma transition from this metastable state is found in the nuclide box Ba 137m. The use of the symbol g indicates that the direct transition to the ground state has a branching greater than 5%. Actually in this case it is 5.3%. Decay to an excited state of the daughter Ba 137 is less probable (less than 1%) and gives rise to the weak gamma emission at 284 keV indicated by the entry (284).


Neutron capture in Cs 137 leads to the formation of Cs 138m with a cross section of 0.20 barns, and to Cs 138g with a cross section of 0.07 barns

References


Half-life: 30.08(9) a, Nucl.Data Sheets 108(2007)2173

Electronic Nuclide Charts in Nucleonica

Universal Nuclide Chart (UNC – decay chain simulator)




Nuclide Explorer (connected with other Nucleonica tools)



Universal Nuclide Chart

> Nuclide Explorer



» Actual Chart: Karlsruhe

> Search Nucleonica Documentation

 Nucleonica Search / Radiation Search



> Application Centre


- » Mass Activity Calculator
- » **New:** Mass Activity Converter
- » Decay Engine
- » **New:** Decay Engine++
- » Dosimetry & Shielding
- » Range & Stopping Power
- » In Silico Dosimetry
- » webKORIGEN
- » Decay Engine for Large Nuclide Sets
- » Universal Nuclide Chart
- » Transport & Packaging
- » **New:** e-Ship: radiological transport assistant
- » Nuclide mixtures
- » Nucleonica Scripting
- » Gamma Spectrum Generator
- » Gamma Spectrum Generator Pro
- » Virtual Cloud Chamber
- » Cambio file Converter
- » WESPA
- » **New:** WESPA2
- » Gamma Library
- » webGraph

> Data Centre

- » Physical Constants
- » Nuclide Explorer
- » Nuclide Datasheets (Reference Data, Derived Data, Cross Sections, Radiations)
- » Nuclide Search / Radiation Search
- » Nuclear Data Retrieval (Nuclide Search, Radiation Search, Dose Coefficients)
- » Fission Yields
- » Universal Nuclide Chart


> Knowledge Centre

- » Nuclear News




Universal Nuclide Chart

Click here to access the Universal Nuclide Chart



Nuclear Data in UNC




The Selected Nuclide
is in the middle of the
Chart

Mouse pointer:
For the pointed nuclide
the most important
nuclear data is shown on
the left side

Decay Chain button


Reaction Path button

Decay chain of U-235





Set MinBr(%) to 5%: some decay path are not displayed anymore

E(MeV): causes blinking alarm on
nuclides with higher:
gamma energy * emission probability



Decay chains of U-235 and U-238



Exercises

Universal Nuclide Chart


1. In the decay chain of U-238 find the nuclide which emits gamma photons with 1001 keV.
(Pa-234m)
2. In the decay chain of U-235, Ac-227 has alpha decay with BR 1.38% to Fr-223. Switch of all decays from the display which have less than 2% branching ratio.(MinBR%=2)
3. Switch off the blinking of the Tl-208 on the decay chain of Th-232.

Nuclide Explorer



European
Commission

► Nuclide Explorer




► Actual Chart: Karlsruhe

► Search Nucleonica Documentation

Search

Nuclide Search / Radiation Search



► Application Centre

- Mass Activity Calculator
- **New:** Mass Activity Converter
- Decay Engine
- **New:** Decay Engine++
- Dosimetry & Shielding
- Range & Stopping Power
- In Silico Dosimetry
- webKORIGEN
- Decay Engine for Large Nuclide Sets
- Universal Nuclide Chart
- Transport & Packaging
- **New:** e-Ship: radiological transport assist
- Nuclide mixtures
- Nucleonica Scripting
- Gamma Spectrum Generator
- Gamma Spectrum Generator Pro
- Virtual Cloud Chamber
- Cambio file Converter
- WESPA
- **New:** WESPA2
- Gamma Library
- webGraph


► Data Centre

- Physical Constants
- **Nuclide Explorer**
- Nuclide Datasheets (Reference Data, Derived Data, Cross Sections, Radiations)
- Nuclide Search / Radiation Search
- Nuclear Data Retrieval (Nuclide Search, Radiation Search, Dose Coefficients)
- Fission Yields
- Universal Nuclide Chart

► Knowledge Centre

- Nuclear News

Zoom

Views: 

User defined

Select colour theme:


Karlsruhe

- ☒ alpha
- ☒ beta*
- ☒ ec/beta*
- ☒ IT
- ☒ n
- ☒ SF
- ☒ p
- ☒ ec
- ☒ CE
- ☒ stable

All None

Background

Filter decay modes



Ground state: 3127 nuclides from 3127 Metastable: 425 nuclides from 769 Total: 3281 nuclides from 3896

Colour scheme is changeable

Decay modes can be filtered


Nuclide Tc-99m



European
Commission



Nuclides with alpha, p and n main decay modes and SF nuclides



Nuclide Data Sheets++

» **New:** e-Ship++: radiological transport assistant

» Transport & Packaging

» Nuclide mixtures

» Nucleonica Scripting

» Gamma Spectrum Generator

» Gamma Spectrum Generator Pro

» Virtual Cloud Chamber

» Cambio file Converter

» **New:** WESPA

» Gamma Library

» webGraph

» Data Centre

» Physical Constants

» Nuclide Explorer

» **New:** Nuclide Datasheets++ (Reference Data, Radiations, Decay)


» Nuclide Datasheets

» **New:** Nuclide Search / Radiation Search

» **New:** Dose Coefficients

» Fission Yields

» Universal Nuclide Chart



Nuclide Datasheets++

92 Uranium

Current Chart: Karlsruhe

Element

U

Mass

235



Nuclide selector

Nuclide Explorer

Tabs

Reference Data

Options

Radiations

Description

Derived Data

Cross Sections

Prompt Gammas

» Nucleonica Databases

Nuclide	$^{235}_{92}\text{U}_{143}$		
Density	19.1 g/cm ³		
Mass Excess	40920.456 (± 1823) keV		
Atomic Mass	235.043929918 (± 1957) u		
Half-life	703.8 (± 5) My		
Spin	7/2 ħ		
Parity	-		
Binding Energy	7.59091 MeV/nucleon		
Abundance	0.7204 (± 6) atom %		
Effective Dose Coefficient Inhalation	8.5E-06 (Sv/Bq)		
Effective Dose Coefficient Ingestion	4.7E-08 (Sv/Bq)		
Mean Decay Energies			
Alpha	4.4646 (MeV)		
Electron	50.6717 (keV)		
Photon	163.616 (keV)		
Type of decay	Branching Ratio	Decay Energy,Q	Daughters
α	1	4.6787 (MeV)	90 Th 231
SF	7.2E-11	176.4 (MeV)	undefined
Ne20	8E-12	unknown	82 Pb 215
Ne25	8E-12	unknown	82 Pb 210
Mg28	8E-12	unknown	80 Hg 207
Type of parent decay	Branching Ratio	Decay Energy,Q	Parents
IT	1	7.68E-05 (MeV)	92 U 235m
ec	0.999985	0.1237 (MeV)	93 Np 235
α	0.0006	5.2445 (MeV)	94 Pu 239

Nuclide Data Sheets++

Co57
2.7E2 d

Nuclide Datasheets++ 27 Cobalt

Current Chart: Karlsruhe



Element Mass

Co 57


Reference Data Options Radiations Description Derived Data Cross S

» Nucleonica Databases

Nuclide	⁵⁷ ₂₇ Co ₃₀		
Density	8.86 g/cm ³		
Mass Excess	-59344.204 (± 713) keV		
Atomic Mass	56.936291373 (± 765) u		
Half-life	271.80 (± 5) d		
Spin	7/2 ħ		
Parity	-		
Binding Energy	8.74186 MeV/nucleon		
Abundance	-		
Effective Dose Coefficient Inhalation	1E-09 (Sv/Bq)		
Effective Dose Coefficient Ingestion	2.1E-10 (Sv/Bq)		
Mean Decay Energies			
Alpha	0 (MeV)		
Electron	18.2925 (keV)		
Photon	125.216 (keV)		
Type of decay	Branching Ratio	Decay Energy,Q	Daughters
ec	1	0.836 (MeV)	²⁶ Fe ⁵⁷
Type of parent decay	Branching Ratio	Decay Energy,Q	Parents
ec/β+	1	3.2642 (MeV)	²⁸ Ni ⁵⁷



Co 57: Extract from the Karlsruhe Nuclide Chart



Co 57 Decay Scheme

Compare databases



European

	JEFF-3.1	ENDF/B-VII.1	Nubase 2003	Nubase 2012	ICRP-72
⁵⁷₂₇Co₃₀					
Density					
Mass Excess			-59344.204 (± 713) keV	-59344.948 (± 619) keV	
Atomic Mass			56.936291373 (± 765) u	56.936290574 (± 664) u	
Half-life	271.80 (± 5) d	271.74 (± 6) d	271.74 d 0.06	271.74 d 0.06	
Spin	7/2 h	7/2 h	7/2-	7/2-	
Parity	-	-			
Binding Energy			8.74186 MeV/nucleon	8.74187 MeV/nucleon	
Abundance			-	-	
Effective Dose Coefficient Inhalation					1E-09 (Sv/Bq)
Effective Dose Coefficient Ingestion					2.1E-10 (Sv/Bq)
Mean Decay Energies					
Alpha	0 (MeV)	0 MeV			
Electron	18.2925 (keV)	18.6615 keV			
Photon	125.216 (keV)	125.143 keV			
Decay					
Co57 (ec) ²⁶ Fe ⁵⁷	Branching ratio	1			
	Decay Energy, Q	0.836 (MeV)	0.836 (MeV)		
Decay Production					
²⁸ Ni ⁵⁷ (ecβ+) Co57	Branching ratio	1			
	Decay Energy, Q	3.2642 (MeV)	3.2622 (MeV)		

Download ☒ Excel ☐ CSV Separator: Semicolon (;) ☒ Use field qualifier (")

⁵⁷₂₇Co₃₀ ☒ gamma ☐ ec/beta⁺ ☐ discrete e⁻ ☐ X-rays & annihilation

Type	Energy(keV) JEFF-3.1	Energy(keV) ENDF/B-VII.1	Emission Probability JEFF-3.1	Emission Probability ENDF/B-VII.1
γ	122.061 (± 0.000)	122.0607 (± 0.0001)	8.5510e-1 (± 6.0e-4)	8.560e-1 (± 1.7e-3)
γ	136.474 (± 0.000)	136.4736 (± 0.0003)	1.071e-1 (± 1.5e-3)	1.0680e-1 (± 8.0e-4)
γ	14.413 (± 0.000)	14.4129 (± 0.0006)	9.15e-2 (± 1.7e-3)	9.16e-2 (± 1.5e-3)
γ	692.010 (± 0.020)	692.410 (± 0.070)	1.590e-3 (± 6.0e-5)	1.49e-3 (± 1.0e-4)
γ	569.940 (± 0.040)	570.090 (± 0.200)	1.50e-4 (± 2.0e-5)	1.580e-4 (± 1.0e-5)
γ	706.420 (± 0.020)	706.540 (± 0.220)	5.00e-5 (± 5.0e-6)	5.00e-5 (± 5.0e-6)
γ	339.670 (± 0.030)	339.690 (± 0.210)	3.80e-5 (± 4.0e-6)	3.70e-5 (± 3.0e-6)
γ	352.340 (± 0.020)	352.330 (± 0.210)	3.20e-5 (± 4.0e-6)	3.00e-5 (± 3.0e-6)
γ	366.740 (± 0.030)	366.800 (± 0.300)	1.30e-5 (± 4.0e-6)	1.20e-5 (± 3.0e-6)
γ	230.270 (± 0.030)	230.400 (± 0.400)	4.0e-6 (± 4.0e-6)	4.0e-6 (± 4.0e-6)

Reference Data Options Radiations

☐ Nucleonica standard

☒ Compare Databases

☒ JEFF-3.1

☒ ENDF/B-VII.1

☒ Nubase 2003

☒ Nubase 2012

☒ ICRP 72

☐ Other

Exercises

Nuclide Explorer

1. Switch the colour scheme of Nuclide Explorer to Binding Energy scheme, after that to General Electric scheme and at the end switch it back to Karlsruhe colour scheme.
2. Switch off the colours of all radioactive nuclides. Switch on the colours after.
3. Select the Nuclide Cs 137 in View: Resolution 9.

Nuclide Data Sheets++


1. What are the daughters of Cs-137? What is the most important gamma line of Cs-137?(283.5 keV, EP=5.8E-6)
2. What is the daughter of Ba-137m? What is the most important gamma line of Ba-137m?(661 keV, EP=90.1%)
3. For the decay of Pu-239, what is the maximum alpha particle **energy**?(5.156 MeV)

Nuclide Data Search



► Data Centre

- » Physical Constants
- » Nuclide Explorer
- » **New:** Nuclide Datasheets++ (Reference Data, Radiations, Derived Data, Cross Sections)
- » Nuclide Datasheets
- » **New:** Nuclide Search / Radiation Search
- » **New:** Dose Coefficients
- » Fission Yields
- » Universal Nuclide Chart



Nuclide Search / Radiation Search

Version: 2011

Questions, remarks, suggestions can be posted here

Nuclide Search

Radiation Search

Advanced Search

Atomic number Z:

Element:

Mass number A:

-

Half-life

d

-

wk

☐ Stable/Primordial

☐ Isomers

☐ Decay Mode

Search

Clear

Table display options

- ☒ Decay mode
- ☒ Parity
- ☒ Half-life
- ☒ Daughter
- ☒ Abundance
- ☒ Branching Ratio
- ☒ Spin
- ☒ Q-Value

CPU time / Total time (sec): 0.39 / 1.4

Search returned 5 results, Number of nuclides: 3

Nuclides	Decay	Half-life	Abundance (atom %)	Spin (h)	Parity	Daughter	Branching ratio	Q-Value (MeV)
83 Bi 205	ec/β+	15.31 (± 4) d		9/2	-	82 Pb 205	0.858	2.7081
83 Bi 205	ec/β+	15.31 (± 4) d		9/2	-	82 Pb 205m	0.142	1.69426
83 Bi 206	ec/β+	6.243 (± 3) d		6	+	82 Pb 206	1.00	3.758
83 Bi 210	β-	5.012 (± 5) d		1	-	84 Po 210	1.00	1.1613
83 Bi 210	α	5.012 (± 5) d		1	-	81 Ti 206	1.32e-6	5.0364
3	5	Page: 1 / 1						

Download

☐ Excel

☒ CSV

Separator: Semicolon (;)

☒ Use field qualifier (")

Datasheets

Radiation search



Nuclide Search Radiation Search Advanced Search

☒ Gamma and X-Rays

Energy: 28 +/- 1 keV

☐ Alpha

60 +/- 1 keV

102 +/- 1 keV

Emission probability: -

Atomic number Z: Element: ▼

Mass number A: -

Half-life: S - S

Table display options

☐ Energy uncertainty

☐ E.P. uncertainty

☒ Half-life

☐ FD

Search Clear

Search returned 19 results, Number of nuclides:

Datasheets

Nuclides	Gamma and X-rays (keV)	Emission Probability	Half-life
95 Am 241	102.96	0.000209	432.8 (± 7) y
91 Pa 231	102.85	0.00171	32.76 (± 11) ky
91 Pa 231	102.8	0.00015	32.76 (± 11) ky
91 Pa 231	102.1	0.000896	32.76 (± 11) ky
91 Pa 228	102	0.00042	22 (± 1) h
67 Ho 161	101.99	0.000156	2.48 (± 12) h
95 Am 241	101.07	2.07E-05	432.8 (± 7) y
91 Pa 231	60.5	5.5E-05	32.76 (± 11) ky
91 Pa 228	60.3	9.7E-05	22 (± 1) h
91 Pa 228	60.3	9.7E-05	22 (± 1) h
91 Pa 228	59.8	2.8E-05	22 (± 1) h
95 Am 241	59.5412	0.36	432.8 (± 7) y
67 Ho 161	59.24	0.00605	2.48 (± 12) h
91 Pa 228	28.8	0.000152	22 (± 1) h
67 Ho 161	28.69	1.17E-05	2.48 (± 12) h
95 Am 241	28.51	2.77E-05	432.8 (± 7) y
91 Pa 228	28.3	2E-05	22 (± 1) h
91 Pa 231	27.36	0.111	32.76 (± 11) ky
95 Am 241	27.04	0.00626	432.8 (± 7) y
4	19	Page: 1 / 1	

Element Mass
Am 241

Reference Data Options Radiations Description Derived Data Cross Sections Prompt Gammas

☒ JEFF-3.1


☐ 8th Table of Radioactive Isotopes

☒ gamma

☐ alpha

☐ discrete e⁻

☐ X-rays & annihilation



Show graph settings

Download SVG image

Show details

Type	E (keV)	Emission probability
γ	59.5412	3.600e-1
γ	26.3448	2.430e-2
γ	27.040	6.26e-3
γ	33.1964	1.217e-3
γ	43.420	6.59e-4
γ	42.720	3.9e-4
γ	98.970	2.23e-4
γ	102.960	2.09e-4
γ	55.550	1.84e-4
γ	125.310	4.10e-5
γ	69.760	2.88e-5
γ	28.510	2.77e-5
γ	123.000	1.080e-5
γ	208.000	7.81e-6
γ	64.820	5.76e-6
γ	75.920	5.76e-6
γ	51.010	5.40e-6
γ	335.390	4.968e-6
γ	146.550	4.50e-6
γ	662.410	3.600e-6
γ	135.300	2.74e-6
γ	54.080	2.66e-6
γ	67.450	2.2e-6
γ	368.590	2.160e-6
γ	169.560	1.620e-6
1	185	Page: 1 / 8

Download

Excel CSV


Separator: Semicolon (;)

Exercise




Nuclear Data Search

1. Find the nuclides with gamma lines at 81, 303 and 356 keV with an uncertainty of ± 1 keV. (Pa-228, Ba-133)
2. Find the Cs isotopes which have a half-life in the range of weeks -100 years. (Cs-134, Cs-137)
3. See gamma spectrum below – to which isotope does this correspond? (Y-88 or Rb-88)



Dose Coefficients (ICRP 68 & 72)

European
Commission



Dose Coefficients, ICRP 68 & 72

ICRP Database Search

Data source	Type	Element(s)	
<input checked="" type="checkbox"/> ICRP 68	<input checked="" type="checkbox"/> Ingestion	<input checked="" type="radio"/> Element	Pu ▾
<input checked="" type="checkbox"/> ICRP 72	<input checked="" type="checkbox"/> Inhalation	<input type="radio"/> All	

Search returned 13 results

Nuclides	ICRP 68 Inhalation $e(50)_{inh}$ (Sv/Bq)	ICRP 68 Ingestion $e(50)_{ing}$ (Sv/Bq)	ICRP 72 Inhalation $e(50)_{inh}$ (Sv/Bq)	ICRP 72 Ingestion $e(50)_{ing}$ (Sv/Bq)
94 Pu 234	2.2E-08	1.6E-10	2.4E-08	1.6E-10
94 Pu 235	2.6E-12	2.1E-12	1.5E-12	2.1E-12
94 Pu 236	1.8E-05	8.6E-08	1E-05	8.7E-08
94 Pu 237	3.6E-10	1E-10	3.9E-10	1E-10
94 Pu 238	4.3E-05	2.3E-07	0.00011	2.3E-07
94 Pu 239	4.7E-05	2.5E-07	0.00012	2.5E-07
94 Pu 240	4.7E-05	2.5E-07	0.00012	2.5E-07
94 Pu 241	8.5E-07	4.7E-09	2.3E-06	4.8E-09
94 Pu 242	4.4E-05	2.4E-07	0.00011	2.4E-07
94 Pu 243	1.1E-10	8.5E-11	8.6E-11	8.5E-11
94 Pu 244	4.4E-05	2.4E-07	0.00011	2.4E-07
94 Pu 245	6.5E-10	7.2E-10	4.3E-10	7.2E-10
94 Pu 246	7.6E-09	3.3E-09	8E-09	3.3E-09
13	Page: 1 / 1			

Download ☒ Excel ☐ CSV Separator: Semicolon (;) ☒ Use field qualifier (")

Help:Dose Coefficients (ICRP 68 & 72)

Level: Intermediate

[Contents](#) [\[show\]](#)

Introduction

A measure of the hazard of nuclear material is provided by the toxicity and in particular the radiotoxicity arising from its radioactive “quality” rather than the chemical toxicity. The radiotoxicity of a nuclide is determined by its effective dose coefficient $e(T)$, which accounts for radiation and tissue weighting factors, metabolic and biokinetic information. The quantity T is the integration time in years following intake. For adults, the integration time is 50 years, such that the radiotoxicity (in Sievert, Sv) or committed effective dose resulting from intake of a particular nuclide is the product of the effective dose coefficient (units Sv/Bq) and the activity (in Bq) of that nuclide i.e.

Committed effective dose = Activity · $e(50)$.

The two main pathways for intake of a radionuclide are through ingestion and inhalation. Accordingly one can differentiate between the ingestion dose coefficient $e_{ing}(50)$ and the inhalation dose coefficient $e_{inh}(50)$.

Physical Constants, Conversion Factors, Radiological limits...

Physical Constants

Conversion Factors

Prefixes / Greek Alphabet

Radiological Limits

Physical Constants

Quantity	Symbol	Numerical Value	Uncertainty	Unit	Name In Script
Speed of light in vacuum	c	299792458	0	ms^{-1}	Const_c
Newtonian constant of gravitation	G	6.67428E-11	67	$\text{m}^3\text{kg}^{-1}\text{s}^{-2}$	Const_G
Magnetic constant	μ_0	1.2566370614E-06	0	N/A^2	Const_mu0
Electric constant	ϵ_0	8.854187817E-12	0	Fm^{-1}	Const_eps0
Planck constant	h	6.62606896E-34	33	J s	Const_planck
reduced Planck constant	\hbar	1.054571628E-34	53	J s	Const_planck_2pi
Atomic mass constant	u	1.660538782E-27	83	kg	Const_u
Energy equivalent of atomic mass constant	u	931.494028	23	MeV	Const_u_energy
Neutron mass	m_n	1.674927211E-27	84	kg	Const_mn
Neutron mass	m_n	1.00866491597	43	u	Const_mn_u
Neutron mass	m_n	939.565346	23	MeV	Const_mn_energy
Proton mass	m_p	1.672621637E-27	83	kg	Const_mp
Proton mass	m_p	1.00727646677	10	u	Const_mp_u
Proton mass	m_p	938.272013	23	MeV	Const_mp_energy
Electron mass	m_e	9.10938215E-31	45	kg	Const_me
Electron mass	m_e	0.00054857990943	23	u	Const_me_u

Physical Constants, Conversion Factors, Radiological limits...

Physical Constants

Conversion Factors

Prefixes / Greek Alphabet

Radiological Limits

Radiological Limits

Workers

Apprentices and Students

Members of the Public

Workers

Dose Limits for exposed workers	Euratom	ICRP	IAEA	Germany
Limit on effective dose for exposed workers in a consecutive 5 years period:	100 mSv	20 mSv/y	20 mSv/y	20 mSv/y
Maximum effective dose in any single year:	50 mSv/y	50 mSv/y	50 mSv/y	50 mSv/y
Equivalent dose limit to the foetus, accumulated over the period of time between declaration of pregnancy to the delivery date:	1 mSv	2 mSv		1 mSv
Pregnant woman				2 mSv/m
Total work life (50 y)				400 mSv
Partial body exposure:				
Limit on equivalent dose for the lens of the eyes:	150 mSv/y	150 mSv/y	150 mSv/y	150 mSv/y
Limit on equivalent dose for the skin:	500 mSv/y	500 mSv/y	500 mSv/y	500 mSv/y
Limit on equivalent dose for the hands, forearms, feet and ankles:	500 mSv/y	500 mSv/y	500 mSv/y	500 mSv/y

Fission Yields

Fission Yield: Number of atoms of a **specific nuclide** produced per 100 fission reactions

Independent Fission Yields: direct production of specific atoms - decay excluded

Cumulative Fission Yields: direct production + via decay

Chain Yield: Atoms of specific isobars ($A=\text{const}$) per 100 fission reactions
(KNC: U-235 and Pu-239 yields)

Te 137 2.5 s β^- 6.3, 6.8... γ 243, 554 469... βn	Te 138 1.4 s β^- βn	Te 139 >300 ns $\beta^-?$ $\beta n?$	Te 140 >300 ns $\beta^-?$ $\beta n?$	Te 141 >300 ns $\beta^-?$ $\beta n?$
Sb 136 923 ms β^- βn	Sb 137 492 ms β^- βn	Sb 138 350 ms β^- βn	Sb 139 93 ms β^- βn	Sb 140 >230 ns $\beta^-?$ $\beta n?$
Sn 135 530 ms β^- 8.9... γ 282, 925, 733 1207... βn	Sn 136 300 ms β^- βn	Sn 137 273 ms β^- βn	Sn 138 >230 ns $\beta^-?$ $\beta n?$	6.345 5.968
In 134 140 ms β^- βn	In 135 92 ms β^- βn	6.57 6.99	6.221 6.594	6.72 6.11


Fission Yields Module

> Application Centre

- >> Mass Activity Calculator
- >> **New:** Mass Activity Converter
- >> Decay Engine
- >> **New:** Decay Engine++
- >> Dosimetry & Shielding
- >> Range & Stopping Power
- >> In Silico Dosimetry
- >> webKORIGEN
- >> Decay Engine for Large Nuclide Sets
- >> Universal Nuclide Chart
- >> Transport & Packaging
- >> **New:** e-Ship: radiological transport assistant
- >> Nuclide mixtures
- >> Nucleonica Scripting
- >> Gamma Spectrum Generator
- >> Gamma Spectrum Generator Pro
- >> Virtual Cloud Chamber
- >> Cambio file Converter
- >> WESPA
- >> **New:** WESPA2
- >> Gamma Library
- >> webGraph

> Data Centre

- >> Physical Constants
- >> Nuclide Explorer
- >> Nuclide Datasheets (Reference Data, Derived Data, Cross Sections, Radiations)
- >> Nuclide Search / Radiation Search
- >> Nuclear Data Retrieval (Nuclide Search, Radiation Search, Dose Coefficients)
- >> Fission Yields
- >> Universal Nuclide Chart



Fission Yields 94 Plutonium

Current Chart: Karlsruhe

Element: Mass:

Pu 239

Select Fission Yields

Library: JEFF-3.1

Type of fission: Thermal fission

Fission Yields Settings

Element

Mass Number

Min Half-life

1

Days

Max Half-life

Seconds



Advanced comparison


Results

Reset

Fission products of Pu-239

Total number of fission products: 306

	Nuclide	Half-life	Independent Yield	Error	Cumulative Yield	Error
Compare	52 Te 132	3.204 (± 13) d	2.94E-02	4.47E-03	5.09E-02	9.36E-04
Compare	54 Xe 136	2.10E+20 (± 0) y	2.70E-02	5.72E-03	6.90E-02	2.53E-03
Compare	56 Ba 140	12.765 (± 15) d	8.76E-03	2.84E-03	5.32E-02	5.86E-04
Compare	52 Te 131m	1.250 (± 8) d	6.85E-03	1.89E-03	9.04E-03	1.45E-03
Compare	40 Zr 96	3.9E+19 (± 9) y	5.82E-03	1.98E-03	4.93E-02	1.53E-03
Compare	55 Cs 137	30.04 (± 3) y	4.57E-03	1.62E-03	6.59E-02	8.03E-04
Compare	44 Ru 106	1.020 (± 2) y	2.98E-03	1.04E-03	4.19E-02	9.21E-04
Compare	52 Te 130	7.90E+23 (± 100) y	2.68E-03	7.95E-04	2.79E-02	6.70E-03
Compare	2 He 4	Stable	2.19E-03	1.18E-04	2.19E-03	8.98E-05
Compare	50 Sn 126	230 (± 14) ky	2.02E-03	3.86E-04	2.64E-03	4.71E-04
Compare	60 Nd 150	2.1E+19 (± 5) y	1.87E-03	5.22E-04	9.75E-03	1.27E-04
Compare	58 Ce 144	285.0 (± 2) d	1.63E-03	6.02E-04	3.75E-02	3.00E-04
Compare	42 Mo 100	9.9E+18 (± 7) y	1.44E-03	5.72E-04	6.84E-02	9.98E-03
Compare	40 Zr 95	64.032 (± 6) d	1.33E-03	4.84E-04	4.95E-02	9.90E-04
Compare	36 Kr 86	Stable	9.19E-04	3.01E-04	7.83E-03	1.85E-04
Compare	34 Se 82	1.21E+20 (± 17) y	8.29E-04	2.30E-04	2.31E-03	4.11E-04
Compare	51 Sb 127	3.85 (± 5) d	7.72E-04	2.50E-04	4.60E-03	2.67E-04
Compare	54 Xe 134	1.1E+16 (± 0) y	6.79E-04	2.40E-04	6.87E-02	3.57E-03
Compare	55 Cs 136	13.03 (± 7) d	5.88E-04	2.07E-04	7.60E-04	2.15E-04
Compare	38 Sr 90	28.79 (± 6) y	5.66E-04	2.07E-04	2.01E-02	
Compare	50 Sn 124	1.00E+17 (± 0) y	5.09E-04	1.25E-04	1.26E-03	
Compare	50 Sn 125	9.64 (± 3) d	4.99E-04	9.46E-05	5.46E-04	
Compare	56 Ba 138	Stable	4.70E-04	1.77E-04	6.11E-02	
Compare	58 Ce 143	1.379 (± 2) d	3.09E-04	1.15E-04	4.48E-02	
Compare	53 I 131	8.0233 (± 19) d	2.34E-04	8.14E-05	3.72E-02	
Compare	40 Zr 94	6.0E+15 (± 0) y	1.98E-04	7.28E-05	4.32E-02	
Compare	42 Mo 99	2.7475 (± 4) d	1.91E-04	6.85E-05	6.18E-02	
Compare	52 Te 129m	33.6 (± 1) d	1.87E-04	6.55E-05	5.65E-03	
Compare	51 Sb 126	12.4 (± 1) d	1.80E-04	6.21E-05	2.22E-04	
Compare	54 Xe 133m	2.188 (± 11) d	1.72E-04	6.25E-05	2.16E-03	
Compare	1 H 3	12.33 (± 2) y	1.42E-04	1.09E-05	1.42E-04	
Compare	61 Pm 151	1.1833 (± 16) d	1.40E-04	4.79E-05	7.76E-03	



Comparison of fissioning system

Libraries

Cs-137 for Pu-239 Thermal fission JEFF-3.1 library

S: Spontaneous fission
T: Thermal neutron induced fission
F: Fast neutron induced fission
H: High energy (14 MeV fusion neutrons) neutron induced fission

	JEFF-3.1-Pu239T	Pu239F	U235T	U238F	U233F
Independent Yield	4.57E-03	6.95E-03	7.22E-04	4.36E-05	9.21E-03
Error (I)	1.62E-03	2.48E-03	2.56E-04	1.59E-05	2.83E-03
Cumulative Yield	6.59E-02	6.35E-02	6.22E-02	6.02E-02	6.50E-02
Error (C)	8.03E-04	1.21E-03	6.94E-04	1.52E-03	3.12E-03
Y(A)	6.71E-02	6.45E-02	6.24E-02	6.21E-02	6.58E-02
Error (A)	1.29E-02	1.25E-02	1.25E-02	1.20E-02	1.27E-02

Exercises

Fission Yields

1. Find the thermal neutron fission products of U-235. How many fission products are listed in JEFF? (977)
2. Which fission products have the highest yields? Give cumulative and independent. (Te-134, Xe-134)
3. What is the cumulative fission yield of Cs-137? (6.22E-2 or 6.22%)

Overview

Nuclide Charts

Karlsruhe Chart of Nuclides

Electronic Nuclide Charts in Nucleonica

Nuclear Data Search in Nucleonica

Fission Yields

Thank You