

**10<sup>th</sup> NUCLEONICA Training Course, Cesme, Turkey, 8-10<sup>th</sup> Oct.  
2008**

# **RANGE AND STOPPING POWER CALCULATIONS IN NUCLEONICA**

**M.Ç. TUFAN**

Ondokuz Mayıs University, Faculty of Arts and Sciences,  
Physics Department, 55139 Samsun, TURKEY



# Range & Stopping Power in Nucleonica

**Stopping Power;** energy loss of energetic particles per unit length in matter.


**The range;** the mean path length of the particle in the target matter before coming to rest.

## Types of Interactions

### I. Inelastic scattering on atomic orbital electrons.


It leads to excitations and ionizations of atoms of the medium, and is called

“Collisional Stopping Power”



### II. Inelastic nuclear scattering.

This results in radiation which is known as “Bremsstrahlung”, so the stopping power is the “Radiative Stopping Power”




# Range & Stopping Power in Nucleonica


**Aurora Borealis:** interaction of electrons with oxygen and molecular nitrogen.



**Čerenkov radiation:** is radiation emitted when a charged particle) passes through matter at a speed greater than the speed of light in that medium. The characteristic "blue glow" of nuclear reactors is due to Čerenkov radiation.



**Proton therapy:** (used in treatment of tumours): 230 MeV p can penetrate in 32 cm tissue



wide application area: ion implantation, fundamental particle physics, nuclear physics, radiation damage, radiology, Rutherford backscattering spectroscopy, and plasma-first wall interaction in a nuclear-fusion reactor

# Range & Stopping Power in Nucleonica

10th NUCLEONICA Training Course, Çeşme, TURKEY

4

## Some Pioneers:

“Les rayons alpha sont des projectiles matériels susceptibles de perdre de leur vitesse en traversant la matière” (1900)



H. Becquerel



P. Curie

M. Curie-Slodowska



E. Rutherford








N. Bohr

E. Fermi



E. Schrödinger



1896

1911

today....

nucleonica



# Range & Stopping Power in Nucleonica

## SHORT HISTORY

- The first study for scattering for two point charge was made by J.J. Thomson.
- In 1909, Geiger and Marsden experimented that scattering of alpha particles from gold foil and they observed that 0.1% of alpha particles backscattered from the target.
- Two years later from this experiment, E. Rutherford theoretically showed why this back scattering occurred, so nucleus was been found.
- After these improvements, in 1913 the energy loss of traversing particles per unit path (stopping power) was calculated theoretically by N. Bohr.
- The first quantum mechanical treatment was done by Bethe in 1930

# Range & Stopping Power in Nucleonica

## Stopping power was studied

- for understanding atomic structure at the beginning of 20. century.
- in 1920's for developing quantum mechanical scattering theory.
- for nuclear fission in 1930's and 1940's, in 1950's for nuclear physics.
- in 1960's for technological applications of ion implantation.
- in 1970's for material analyzing and radiation oncology.

# Range & Stopping Power in Nucleonica

## Physics Behind the RANGE Module

- The RANGE module uses the SRIM "engine" for heavy ions, alphas and protons.
- Own codes for the calculations for electron, positron and muon projectiles.
- The interaction of incident electrons with target electrons can be calculated from Bethe's theory.
- The collisional stopping power of matter is calculated by considering the effective charge approximation.
- For Radiative Stopping Power, RANGE module uses simple ratio:

$$S_{\text{rad}}/S_{\text{coll}} = ZE/800$$

- Range of the electrons, positrons and muons in matter is calculated by using Continuous Slowing Down Approximation (CSDA):

$$R(E) = \int_{E_{\text{abs}}}^E \frac{dE'}{S(E')}$$

## Projectile:

alpha  
electron  
positron  
proton  
alpha  
muon  
other ions

Energy (MeV)  
Energy (MeV)  
Energy (MeV)/amu  
Speed (m/s)  
Speed (w/c)

## Target: Mono-

Actinium  
Aluminum  
Antimony  
Argon  
Arsenic  
Astatine  
Barium  
Beryllium  
Bismuth  
Boron  
Bromine  
Cadmium  
Calcium  
Carbon  
Cerium  
Cesium  
Chlorine  
Chromium  
Cobalt  
Copper  
Dysprosium  
Erbium  
Europium  
Fluorine  
Francium  
Gadolinium  
Gallium  
Germanium  
Gold  
Hafnium

## Main Interface:

### Range & Stopping Power

Input Details Compound Details Options

**Input**

Projectile

Projectile Ion: alpha

Energy (MeV): 200

Target

Actinium

Density (g/cm<sup>3</sup>): 10

☒ Mono-element ☒ Solid

☐ Predefined compound ☐ Gas

☐ User defined compound

Run

## Target: User-Defined Compounds:

Input Details Compound Details Options

**Compound composition**

User defined compound: sodium iodide Save Delete

Z	Element	Atomic Weight	Stoichiometry
53	Iodine	126.9000	1

Add Remove Remove All

	Z	Element	Atomic Weight	Stoichiometry	Atom %
Edit	11	Sodium	22.99	1	50
Edit	53	Iodine	126.9	1	50



## Wiki Help:

**Test Results for Alphas**

In this section, we give the results of stopping power and ranges for alphas in H (gas), Pb (solid) and water (liquid). We have compared the results for RANGE module with those from ASTAR. Obtained results are shown in the figs.7-12 for these targets.



### Alphas in H (Gas)

Calculated results are shown in fig. 7 for stopping power and in fig. 8 for range. We have also given the mean errors in tables (see figs.7-8) for stopping power and for range, respectively.



### Alphas in Pb (Solid)

The calculations of stopping power and range for the alphas were carried out in Pb to test solid targets. Obtained results are shown in figs. 9 and 10 for stopping power and range, respectively. As can be seen from the figures, obtained results are quite agree with the results of ASTAR.



## Target: Pre-Defined

Target

Acetone

Acetone  
Air (dry, near sea level)  
Aluminium oxide  
Ammonia  
Brass  
Bronze  
Concrete  
CR-39  
Glass (Pb transparent)  
Graphite (Carbon)  
Lexan  
Methanol  
Paraffin  
Photographic emulsion  
Plexiglass  
Scintillator NaI  
Skin human  
Soft Tissue (ICRP)  
Stainless steel  
Teflon  
Water (liquid)  
Water (vannin)



# Results:

```

=====
Calculation using SRIM-2006
SRIM version --->
Calc. date ---> April 07, 2008
=====

Disk File Name = range_out2.txt

Ion = Helium      [2] , Mass = 4.002603 amu

Density = 1.0000E+00 g/cm3 = 4.4282E+22 atoms/cm3
===== Target Composition =====
Atom  Atom  Atomic  Mass
Name  Numb  Percent Percent
-----
H      1     010.45  000.77
C      6     023.22  020.51
N      7      002.49  002.56
O      8      063.02  074.15
Na     11     000.11  000.19
Mg     12     000.01  000.02
P      15     000.13  000.30
S      16     000.20  000.47
Cl     17     000.13  000.35
K      19     000.20  000.57
Ca     20     000.02  000.07
Fe     26     000.01  000.02
Zn     30     000.00  000.01
=====
Bragg Correction = 0.00%
Stopping Units = keV/(mg/cm2)
See bottom of Table for other Stopping units

Ion = Helium      [2] , Mass = 4.002603 amu

```

Ion Energy	dE/dx Elec.	dE/dx Nuclear	Projected Range
999.999 eV	9.609E+01	1.382E+02	224 A
1.10 keV	1.008E+02	1.364E+02	246 A
1.20 keV	1.053E+02	1.346E+02	267 A
1.30 keV	1.096E+02	1.328E+02	288 A

## Range & Stopping Power

Input Details Compound Details Options

**Input**



Projectile Ion:    
 Energy (MeV):

**Target**

Target:    
 Density (g/cm<sup>3</sup>):   
☐ Mono-element ☒ Solid  
☒ Predefined compound ☐ Gas  
☐ User defined compound

**Results**


Projected range, R: 4.460E+1  $\mu\text{m}$   
 Mass thickness: 4.460E-3 g/cm<sup>2</sup>  
 Stopping Power (total): 7.669E+2 keV/(mg/cm<sup>2</sup>)



nucleonica



## Target: User-defined compounds



### Range & Stopping Power

Input

Details

Compound Details

Options

#### Compound composition

User defined compound

Z

Element

Atomic Weight

Stoichiometry

▼

▼

	Z	Element	Atomic Weight	Stoichiometry	Atom %
Edit	1	Hydrogen	1.008	4	80
Edit	6	Carbon	12.011	1	20

nucleonica



# Wiki Help:

## Range Calculations

Most of the transport calculations and Monte Carlo simulations for the calculation of Range are based on the so-called Continuous Slowing Down Approximation (CSDA). In this approximation, it is assumed that the particle loses its energy in a continuous way and at a rate equal to the stopping power. Since the stopping power is the energy loss of projectile per unit path, CSDA range (or Bethe range) is calculated by

$$R(E) = \int_{E_{abs}}^E \frac{dE'}{S(E')}$$

where  $E_{abs}$  is the energy where particle is effectively absorbed. CSDA range is the path length traveled by the particle and since energy-loss fluctuations are not considered, CSDA range is always higher than projected range ( $R_p$ ) which is the distance between the point where particle enters the stopping medium and the point where particle is absorbed (or come to rest). It becomes important when the projectile's energy is low enough.

SRIM uses PRAL (Projected Range ALgorithm) [6] equations for calculating projected range. To second order it involves iterating the difference equation

$$R_p(E_0 + \Delta E_0) = R_p(E_0) + \left[ \frac{4E^2 - (2E\mu S_n + \mu Q_n)R_p(E_0)}{4ES_t - 2\mu Q_n} \right] \frac{\Delta E_0}{E}$$

## Test Results for Protons

We calculated the stopping powers and ranges of H (Gas), Pb (solid) and water (Liquid) for protons and compared the results with PSTAR.

### Protons on H (Gas)

As can be seen in fig.1, overall agreement with PSTAR is quite good. Comparing the RANGE module's results with PSTAR, the overall mean error in energy range from 1 keV to 1 GeV is 0.8 %, mean error is 1.8 % in energies below 400 keV and mean error in energies below 10 keV is 2.5 %.




Figure 1. The stopping power results for protons in H (Gas).




Figure 2. The range results of protons in H (Gas).

[help](#)[discussion](#)[edit](#)[history](#)[delete](#)

## Help:Range & Stopping Power

### Range and Stopping power

[Contents](#) [\[hide\]](#)

- 1 INTRODUCTION
- 2 Bethe Theory of Stopping
- 3 Calculation of Stopping Power and Range for Heavy Ions
  - 3.1 Stopping Power Calculations
    - 3.1.1 Nuclear Stopping
    - 3.1.2 Electronic Stopping
  - 3.2 Range Calculations
- 4 Stopping Power Calculations for Electrons and Positrons
- 5 Stopping Power Calculations for Muons
- 6 Accuracy of the Range Module
  - 6.1 Test Results for Protons
    - 6.1.1 Protons on H (Gas)
    - 6.1.2 Protons on Pb (Solid)
    - 6.1.3 Protons on Water (Liquid)
  - 6.2 Test Results for Alphas
    - 6.2.1 Alphas in H (Gas)
    - 6.2.2 Alphas in Pb (Solid)
    - 6.2.3 Alphas in Water (Liquid)
  - 6.3 Test Results for Electrons
    - 6.3.1 Electrons in H (Gas)
    - 6.3.2 Electrons in Pb (Solid)
    - 6.3.3 Electrons in Water (Liquid)
  - 6.4 Test Results for Positrons
    - 6.4.1 Positrons in air (gas)
    - 6.4.2 Positrons in Pb (solid)
    - 6.4.3 Positrons in water (liquid)
  - 6.5 Test Results for Muons
    - 6.5.1 Muons in H (gas)
    - 6.5.2 Muons in Pb (solid)
    - 6.5.3 Muons in water (liquid)
- 7 Using Range&Stopping Power Module

#### navigation

- [Main Page](#)
- [Community portal](#)
- [Current events](#)
- [Recent changes](#)
- [Random page](#)
- [Help](#)

#### search

#### toolbox

- [What links here](#)
- [Related changes](#)
- [Upload file](#)
- [Special pages](#)
- [Printable version](#)
- [Permanent link](#)

# Range & Stopping Power in Nucleonica

## Range Calculations with Nucleonica Scripting

Scripting language:

Classes	Main Methods
<i>range</i>	<i>CalculateMono()</i>  <i>CalculateCompound()</i>  <i>CalculatePredefinedCompound()</i>  <i>AddCompound()</i>  <i>OriginConfigureSP()</i>  <i>OriginGraphSP()</i>  <i>OriginConfigureRange()</i>  <i>OriginGraphRange()</i>
<i>rangeResult</i>	<i>ProjRange();</i> <i>massthickness();</i>  <i>StragLong(); StragLat();</i> <i>etc.</i>

# Range & Stopping Power in Nucleonica

## CONCLUSIONS

The RANGE module:

- provides a user-friendly interface for quick and accurate calculations on the range and stopping powers of charged particles.
- can calculate SP and Range for electrons, positrons, protons, alphas, muons and heavy ions in a variety of different natural elements, pre-defined and user-defined compounds.
- Test results show agreements of less than 5% for protons and alphas, less than 10% for electrons and positrons, and less than 7% for muons for the total stopping powers and the CSDA Ranges. The Range module uses SRIM for heavy particles with a known accuracy of less than 5%.
- give freedom to the user for selecting the energy and stopping power units.
- provides high quality graphs for SP and Range.
- can be used in the Nucleonica scripting language.

Thanks!



nucleonica

